

				<b>Nardi</b>										
				<b>Classico</b>				<b>Gara</b>				<b>ND 2000</b>		
				Holz	Holz	Leder	Leder	Holz 3	Leder 3	Holz 4	Leder 4	Leder	Holz	
				ND 360 W	ND 390 W	ND 365	ND 390	Gara 3III/W	Gara 3/III	Gara 4/4 W	Gara 4/4	MB 4	ND2000/1 W	ND2000/1
									Gara 3/4	Gara 4/5 W	Gara 4/5		ND2000/2 W	ND2000/2
									Elite 3		Elite 4			
Fahrzeugtyp	Typ	ABE-Nr.	Nabe	Ø 360	Ø 390	Ø 365	Ø 390	Ø 365	Ø 365	Ø 365	Ø 365	Ø 380	Ø 365	Ø 365
<b>Citroen/F</b>														
AX	ZA	E 544/1	0707D	x			x	x	x	x	x	x	x	x
BX, -Break	XB	C 943/1	705	x			x	x	x	x	x	x		
		C 943/2	Gww 0705 E	x										
XM, -Break	Y 3 F 320		0706 D	x19	x19	x19		x19	x19	x 19	x19	x19	x19	x19
			ww0706 G											
ZX	N2 F 834		0707D	x	x		x	x	x	x	x	x	x	x
Xantia	x 1 G 411		3613D	x19			x19	x19	x19	x 19	x19		x	x